

THE WOOD STAIN



VARNISH: HOW TO APPLY

USE	For use on cabinetry, furniture, trim, millwork, etc.
PROJECT PREP	Unfinished surfaces should be sanded with 120 grit prior to applying varnish. Ensure project is free of dust, dirt, conditioners and oils. Remove any sanding dust with tack cloth.
PRODUCT PREPARATION	Shake vigorously for 30 seconds. Stir well making sure to incorporate materials at bottom of can. Stir before and during use.
COVERAGE	1 Quart treats ~100 SQ FT of smooth wood.
APPLICATION	Varnish may be applied with a roller, sprayer or brush. Product looks milky when first applied but dries clear. To avoid bubbles, do not over brush. Use a damp sponge brush to remove any bubbles on the wood's surface. Apply in a well-ventilated area. When using a spray gun, varnish may be thinned up to 10% with water. Do not apply in temperatures below 55°F.
RECOAT	For superior protection, apply up to three coats of varnish, especially in high traffic or water-exposed areas. Apply 2nd coat within 4 hours of applying 1st coat or wait 48 hours.
DRY TIME	Varnish is dry to touch in 60-120 minutes.
CURE TIME	Full cure time 30 days.
CLEAN UP	Easy soap and water clean up.

